



Kodak Scan Station 500



CAT No.	Description
148 4864 	Kodak Feed Rollers Includes: 12 feed rollers and 2 pre-separation pads Usage: See the table for a guideline on how often to change consumables.
173 6115 	Kodak Separation Module Includes: 1 separation module Usage: this module has the potential to scan up to 250,000 pages.
826 9607 	Kodak Feed Module Includes: 1 feed module Usage: this module has the potential to scan up to 500,000 pages.
853 5981 	Kodak Digital Science Roller Cleaning Pads (24 per package) Usage: approximately one pad per day or more frequently if required.
169 0783 	Kodak Digital Science Transport Cleaning Sheets (50 sheets per package) Usage: 2 to 4 sheets per week/per machine.
896 5519 	Staticide Wipes / for Kodak Scanners (6 boxes of 24) Usage: approximately 1 per day.
868 3724 	Optics Cleaner Includes: 1 optics cleaner Usage: Replace when optics cleaner becomes dirty and shows signs of wear.
125 1842 	Kodak Scan Station Portable USB Drive, 512 MB Includes: 5 per package
186 0949 	USB Replacement Connector Includes: 1 connector Usage: replace when worn or damaged.
179 6747 	Kodak A3 Flatbed Accessory Includes: A3 flatbed with black background and 2-meter (6-ft.) cable Usage: for scanning exception documents. Accommodates document sizes up to A3 / 302.7 x 420 mm (11.92 x 18.15 in.)
867 7288 	Kodak A4 Flatbed Accessory Includes: A4 flatbed with white background and 2-meter (6-ft.) cable Usage: for scanning exception documents. Accommodates document sizes up to A4 / 219 x 300 mm (8.62 x 11.81 in.)

Feed Module and Separator Module Guidelines for the Scan Station 500, s1220 Photo Scanner and the i100 / i200 / i1200 / i1300 / i1400 Series Scanners Consumables Kits

The following table provides a guideline of how often to change the feed module, separation roller, pre-separation pad and tires.

- **Feed module and separation roller tires:** tire life will vary depending upon paper types, environment and cleanliness. Nominal tire life is approximately 125,000 pages, results will vary. Degradation of feeder performance, multiple feeds, stoppages, etc. indicate a need to change tires. Change all tires on the feed module and separation roller at the same time.
- **Feed module and separation roller:** it is recommended that you install a new feed module and separation roller approximately every 4th tire change. Install a new feed module and separation roller at the same time.
- **Pre-separation pad:** change every other time you change the feed module, separation roller or change the tires.

Consumables Kit for s1220 / i100 / i200 / i1200 / i1300 / i1400 Series Scanners CAT No. 124 1066 / 148 4864				
	Feed Module Tires	Separation Module Tires	Pre-Separation Pads	Cumulative Pages Scanned
New Feed Module/Separation Roller				0
Change pad/tires	4	2	1	125,000
Change pad/tires	4	2		250,000
Change pad/tires	4	2	1	375,000
Totals	12	6	2	500,000

Extra Large Consumables Kit for s1220 / i100 / i200 / i1400 Series Scanners CAT No. 821 5808				
	Feed Module Tires	Separation Module Tires	Pre-Separation Pads	Cumulative Pages Scanned
New Feed Module/Separator Module				0
Change pad/tires	4	2	1	125,000
Change pad/tires	4	2		250,000
Change pad/tires	4	2	1	375,000
New Feed Module/ Separator Module				500,000
Change pad/tires	4	2	1	625,000
Change pad/tires	4	2		750,000
Change pad/tires	4	2	1	875,000
New Feed Module/ Separator Module				1,000,000
Change pad/tires	4	2	1	1,125,000
Change pad/tires	4	2		1,250,000
Change pad/tires	4	2	1	1,375,000
New Feed Module/ Separator Module				1,500,000
Change pad/tires	4	2	1	1,625,000
Change pad/tires	4	2		1,750,000
Change pad/tires	4	2	1	1,875,000
New Feed Module/ Separator Module				2,000,000
Change pad/tires	4	2	1	2,125,000
Change pad/tires	4	2		2,250,000
Change pad/tires	4	2	1	2,375,000
Totals	60	30	10	2,500,000